

Update your **SISWOO!**

How to install a Rom with FlashTool

1. First of all, you need a ROM for your device, the latest SP Flash Tool version and the Mediatek ADB VCOM driver. You can download all three in our website's downloads section.
2. Install the driver first (If you don't know how, check the tutorial below "How to install the MTK65XX Driver in Windows")*
3. Unpack the Flash Tool and open it up.
4. You will see an interface with multiple tabs. The tab "Firmware Update" should be active. There is also a button called "Scatter Loading". Please click on it.
5. Now navigate to the folder where you unpacked the ROM for your phone and double click on the scatter file (MT6592_Android_scatter_emmc.txt or similar).
6. This will take you back to Flash Tool where you should see the list filled with "PRELOADER, DSP_BL, MBR, EBR1, UBOOT, BOOTIMG" and so on.
7. Everything is set up and we are ready to flash now! Click "Download" (the big button with the green arrow)
8. Now the Flash Tool is waiting for your phone. Take the battery away, wait 5 seconds, put the battery back in and immediately plug the USB cable in. The flash procedure should be started now.
9. Once the flashing process has finished successfully, you should see a window with a green circle. Now you can close everything. Unplug your device and remove the battery again for a few seconds. Then put the battery back in and fire up your phone.
10. The first boot can take a few minutes, so be patient. Have fun with your new ROM!

* How to install the MTK65XX Driver in Windows

11. Download and unzip the driver provided on the Downloads section of our website, place the unzipped folder on your Desktop.
12. Hit the Windows key or open the Start Menu and write "Device Manager" so it will appear on the list, just click on it.
13. Once here, click on your PC's name on the devices list, then go to actions>add hardware. This will open a new window.
14. Follow the steps choosing the manual installation and the installation directory. When you get to the step shown in the image below, choose the second option. Hit "Next" and in the following screen, select the first option: "Show all devices".
15. You will reach a step called "Select the device driver you want to install for this hardware", here you have to click on "Have disk...", then hit "Browse" so you will be able to choose the files from the folder on your Desktop. Select the drivers (you will have to choose the file depending on if you are running a 32 or 64-bit system) and install them. Once you have installed the Mediatek DA USB VCOM Port, repeat the process to install the MediaTek PreLoader USB VCOM Port.
16. Finally, connect your powered up mobile to your computer via USB. It will automatically find and install the drivers.